

MAONO

LAVALIER MICROPHONE


7 BASIC /PRO

USER GUIDE




For optimal setup and usage guidelines, visit maonoglobal.com or scan the QR code with your phone.

LAVALIER MICROPHONE 7 BASIC/PRO




- ① Omni-directional microphone
- ② Battery Compartment
- ③ ON/DSLR Camcorders, etc.
- ④ OFF/Smartphone
- ⑤ 3.5mm (1/8") gold 4-pole mini-plug
- ⑥ Clamp the clip on the concave of microphone
- * ⑦ Gopro cable only available for 7 pro model

LAVALIER MICROPHONE 7 BASIC/PRO



- 1.指向性マイクロホン
- 2.バッテリーコンパートメント
- 3.ON/DSLR ビデオカメラ等
- 4.OFF/スマートフォン
- 5.3.5mm (1/8") ゴールド 4ポール・ミニ・プラグ
- 6.ホルダー
- 7.Goproコネクタ

LAVALIER MICROPHONE 7 BASIC/PRO



Using the microphone

- Passive microphone mode (for mobile phone only), slide the ON/OFF down to OFF/Passive mode and you can use it to record the audio without power supply.
- Active microphone mode (for DSLR, PC, Gopro etc.) Slide the ON/OFF up to ON/Active mode, and you can use it to record the audio with power on.

* Gopro cable only available for 7 pro model.

How to access battery




Unscrew the battery case



Insert the battery case

LAVALIER MICROPHONE 7 BASIC/PRO



マイクロフォン取扱説明

- 受動マイクロフォンモード (スマホ使用) オン/オフのスイッチをオフにすると電池を使用せず、録音できます。
- アクティブなマイクロフォンモード (DSLR、PC、Goproなど使用) オン/オフのスイッチをオンにし録音するには電池による駆動。
- Goproは7プロのモデル使用限りです。

電池の入れ方



ねじる電池ケース



挿入電池ケース

LAVALIER MICROPHONE 7 BASIC/PRO

Specifications (製品の仕様)

